

Installation instructions

Recessed downlight luminaire range

Warning

Electrical products can cause death injury or damage if incorrectly installed. Installation of this product must be carried out by a qualified person in compliance with the requirements of SANS 10142 or the corresponding regulations of the country of installation. The installation of this product may require that a certificate of compliance be updated.


Specification:

Supply 220V-240V 50Hz/60Hz

Power consumption Nom (Driver and model dependant)

IP rating 20 unless marked otherwise

Installation Instruction

- Ensure mains supply is switched off
- Connect incoming supply to the terminals supplied –Live wire to terminal marked 'L'. Neutral wire to terminal marked 'N'
- Earth wire to terminal marked- 
- This luminaire is intended to be installed in ceiling and being supported by the spring latches.
- The luminaire must not be covered by insulation material as this will inhibit its heat dissipation.
- This luminaire has no replacement parts that should be accessed by a layman for any reason.
- Only the manufacturer his service staff or suitably qualified persons as defined in SANS 10142 may access this luminaire.
- The luminaire may upon request also be supplied with a factory fitted flexible cord set not exceeding 3meters.



Caution, risk of electric shock

NOTE: - The light source and components contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person."